




SENSOR PUSH PLATE


INSTALLATION INSTRUCTION

Version 1.0
Article No. P10.0110.0100.9
P10.0111.0100.9
P10.0112.0100.9




SENSOR PUSH PLATE


The adaptor can't be installed exposed, especially under the sunlight.




The adaptor can't be installed in wet surroundings.



Operation with wet hands is forbidden.




Any operation is disallowed when adaptor is connected to power supply.





The size of cable should be 1.0-2.5mm² and the wire connector should be connected firmly.



CAUTION:

Be sure not to place adapter in an inflamm-able box (for example a wooden box).




Disassembly of the product is forbidden.








1




2




3




4




5




6




7




8





9




10




11




12




13




14




15



16



17



AXENT International AG

info@axentbath.ch
www.axentbath.ch